

MQUIK 360° VEHICLE INSPECTION CHECKLIST

BASIC DETAILS

- Customer Name : _____
- Contact : _____
- Vehicle Registration No.: _____
- Make / Model / Variant / Year : _____
- Odometer Reading : _____
- Fuel Level : _____
- Job Card No. & Date : _____
- Service Advisor Name : _____

CUSTOMER COMPLAINTS (In Customer's Words)

- ☐ Noise
- ☐ Vibration
- ☐ Warning Light
- ☐ Low Pickup
- ☐ Poor Mileage
- ☐ Brake Issue
- ☐ Steering Issue
- ☐ AC Issue
- ☐ Other: _____

Advisor must repeat complaint back to customer before inspection

EXTERIOR & SAFETY CHECK (Walk-Around)

- ☐ Headlamps (Low / High)
- ☐ Fog Lamps
- ☐ Indicators / Hazard
- ☐ Tail Lamps / Brake Lamps
- ☐ Wipers & Washer
- ☐ Windshield / Glass Cracks
- ☐ ORVMs / Mirrors
- ☐ Horn
- ☐ Tyre Condition (All 5)
- ☐ Tyre Pressure
- ☐ Wheel Nuts / Bolts

⚠ Critical Safety Observations: _____

MQUIK 360° VEHICLE INSPECTION CHECKLIST

TYRE & SUSPENSION

- ☐ Tyre Inspection Report
- ☐ Wheel Alignment Required
- ☐ Wheel Balancing Required
- ☐ Shock Absorber Leakage
- ☐ Lower Arm / Bush Noise
- ☐ Ball Joint Play
- ☐ Stabilizer Link Noise
- 💰 Opportunity Identified:
 - ☐ Tyre Replacement
 - ☐ Suspension Work

⚠️ Recommendation

- FR Shock Absorber Replace : ☐
- RR Shock Absorber Replace : ☐
- Lower Arm / Bush Replace : ☐
- Suspension OH : ☐
- Ball Joint Replace : ☐
- Tie Rod End Replace : ☐
- Stabilizer Link Replace : ☐
- Steering Assembly Repair / Replace : ☐
- Tyre Replacement : ☐

BRAKING SYSTEM

- ☐ Front Brake Pads
- ☐ Rear Brake Pads / Shoes
- ☐ Disc Condition
- ☐ Brake Fluid Level / Colour
- ☐ Brake Noise
- ☐ Handbrake Performance

⚠️ Recommendation

- Front Brake Pads : Replace ☐
- Rear Brake Pads/Shoes : Replace ☐
- Disc FR : Skimming ☐ Replace ☐
- Disc RR : Skimming ☐ Replace ☐
- Brake Fluid : Top Up ☐ Replace ☐

ENGINE BAY CHECK

- ☐ Engine Oil Level / Condition
- ☐ Coolant Level / Colour
- ☐ Brake Fluid
- ☐ Power Steering Fluid
- ☐ Battery Health / Terminals
- ☐ Belts (Cracks / Noise)
- ☐ Hoses / Leakage
- ☐ Air Filter
- ☐ AC Belt / Compressor Noise
- ☐ Engine Mounting
- ☐ Transmission Mounting

⚠️ Recommendation

- Engine Oil : Top Up ☐ Replace ☐
- Coolant : Top Up ☐ Replace ☐
- Brake Fluid : Top Up ☐ Replace ☐
- Power Steering Fluid : Top Up ☐ Replace ☐
- Battery : OK ☐ Charge ☐ Replace ☐
- Belts : OK ☐ Replace ☐
- Hoses : OK ☐ Replace ☐
- Air Filter : OK ☐ Replace ☐
- AC Belt : OK ☐ Replace ☐
- Engine Mounting Replace ☐
- Transmission Mounting Replace ☐

UNDERBODY INSPECTION

- ☐ Engine Oil Leakage
- ☐ Gearbox Leakage
- ☐ Exhaust Noise / Rust
- ☐ Mountings
- ☐ Drive Shaft / CV Boot
- ☐ Underbody Damage
- ☐ Fuel Line / Brake Line Condition
- ⚠️ Advisor MUST visit vehicle on lift

MQUIK 360° VEHICLE INSPECTION CHECKLIST

ELECTRICAL & DIAGNOSTICS

- ☐ Warning Lights On Dashboard
- ☐ Scan Tool Used
- ☐ Error Codes Found
- ☐ Battery Charging Voltage
- ☐ Alternator Performance

🔧 Codes / Remarks: _____

AC & COMFORT

- ☐ Cooling Performance
- ☐ Blower Noise
- ☐ AC Smell
- ☐ AC Gas Pressure
- ☐ Cabin Filter Condition

⚠️ Recommendation

AC Servicing : ☐
Blower Replace : ☐
Disinfectant Treatment : ☐
Cabin Filter Replace : ☐

10 INTERIOR CHECK

- ☐ Seat Belts
- ☐ Dashboard Warning Lights
- ☐ Power Windows
- ☐ Central Locking
- ☐ Music System / Screen
- ☐ Interior Cleanliness

⚠️ Recommendation

Interior Cleaning : ☐
Speaker Upgrade : ☐
Sound Damping : ☐
Remote Cell Replace : ☐
Winder Repair / replace : ☐

EXTERIOR CHECK

- ☐ Paint Condition
- ☐ Windscreen Glass
- ☐ Wiper Blades

⚠️ Recommendation

Paint Correction : ☐
Glass Polishing : ☐
Wiper Blade Replace : ☐

FINAL RECOMMENDATIONS (MOST IMPORTANT)

🔴 Immediate (Safety / Breakdown Risk)

1. _____
2. _____
3. _____
4. _____

🟡 Recommended (Performance / Longevity)

1. _____
2. _____
3. _____
4. _____

🟢 Preventive (Future Planning)

1. _____
2. _____
3. _____

MQUIK 360° VEHICLE INSPECTION CHECKLIST

CUSTOMER EXPLANATION & APPROVAL

- ☐ Explained with car on lift
- ☐ Photos / Videos shared on WhatsApp
- ☐ Customer Questions Answered

Customer Approval:

☐ Approved | ☐ Deferred | ☐ Declined

INTERNAL CONTROL

- ☐ Inspection Done by Technician
- ☐ Cross-Checked by Floor Supervisor
- ☐ Advisor Verified & Explained

Sr. Technician: _____

Jr. Technician: _____

Advisor: _____

NOTES
